

INSTALLATION GUIDE

NI-Serial for PCI/PXI-843x

This guide includes instructions for installing your PCI/PXI serial hardware and software.

Refer to the *Serial Hardware and Software for Windows Help* (available on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

PCI/PXI Serial Installation

1. Log on as Administrator or as a user with administrator privileges.
2. Insert the *NI-Serial Software for Windows 2000/XP* CD.
3. If the NI-Serial autorun application starts, select **Install Software**, follow the onscreen instructions, and skip to step 5. Otherwise, select **Start»Settings»Control Panel** and then double-click **Add/Remove Programs**.
4. Click **Add New Programs**, **CD** or **Floppy**, and **Next**. When the Run Installation Program window appears, click **Finish** and follow the onscreen instructions.

5. Remove the CD. Power down the computer, install your NI-Serial PCI or PXI hardware, and power on the computer.
6. When you restart the computer, the Found New Hardware Wizard appears. Complete the wizard by clicking **Next** or **Continue Anyway** in each window and then **Finish**.
7. Select **Start»Programs»National Instruments»NI-Serial»Troubleshooting Wizard**.
8. The Troubleshooting Wizard window appears. This application verifies the software and hardware installation and sequentially tests each NI serial port.
9. Connect the cables.

National Instruments™, NI™, and ni.com™ are trademarks of National Instruments Corporation. Product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your CD, or ni.com/patents.